

Timeless Legacy Floors

Haven Installation Guidelines

Dryback
Vinyl

These instructions cover all fully adhered installations of Haven Collections Luxury Vinyl Tile (LVT)

The information on this sheet provides general guidelines:

- The floor covering, adhesive and room temperature must be kept at a minimum temperature of 65°F or warmer for at least 72 hours before, during, or after installation. Maximum temperature must not exceed 95°F.
- Install Haven LVT only after the jobsite has been cleaned and cleared of other trade apparatus that may damage a finished tile installation.
- Always check the cartons to assure the pattern number is correct. To minimize shade variation, mix and install tiles / planks from several different cartons.

- All subfloor / underlayment patching must be done with a non-shrinking water resistant Portland cement patching compound.
- Never install Haven L&C LVT over residual asphalt-type (cut back) adhesive. It can bleed through to the new floor covering.
- Haven can be adhered with either Uzin Utz or Titebond 780 adhesives.

PRO320 can ONLY be glue down. All others are glue down or loose lay.

Careful and correct preparation of the subfloor is an important part of resilient floor covering installation. Roughness or unevenness of the subfloor will telegraph through the new floor covering, resulting in an unsightly surface and excessive uneven wear on high spots.

All surfaces should be flat within 3/16" in 10 feet using appropriate materials to level the substrate.



WOOD SUBFLOORS

1. GENERAL

All wood floors must be suspended at least 18" above the ground. Adequate cross ventilation must be provided, and the ground surface of a crawl space must be covered with a suitable vapor barrier. Wood subfloors directly on concrete or installed over sleeper construction are not satisfactory for the installation of Haven LVT flooring products. Wood subfloors must be covered with a minimum 1/4" or heavier underlayment rated panel to assure a successful finished flooring installation.

2. UNDERLAYMENT

Many times, wood panel subfloors are damaged during the construction process or are not of underlayment grade. These panels must be covered with an approved underlayment. Underlayment panels are intended to be used to provide a smooth surface on which to adhere the finished floor covering. It must be understood that underlayment panels cannot correct structural deficiencies. In all cases, the underlayment manufacturer or underlayment installer is responsible for all underlayment warranties.

3. UNDERLAYMENT REQUIREMENTS

Panels intended to be used as underlayment should be specifically designed for this purpose. These panels should have a minimum thickness of 1/4". Any panels selected as an underlayment must meet the following criteria:

- Be dimensionally stable
- Have a smooth, fully sanded face so the graining or texturing will not show through
- Be resistant to both static and impact indentation
- Be free of any surface components that may cause staining such as plastic fillers, making inks, sealers, etc.
- Be of uniform density, porosity and thickness
- Have a written warranty for suitability and performance from the panel manufacturer or have a history of proven performance.

Any unevenness at joints between panels must be sanded to a level surface. Gaps between panels, hammer indentations, and all other surface irregularities must be patched.



WOOD SUBFLOORS

4. FLOOR CONSTRUCTION

Subfloor construction, when using glue down or loose-lay Luxury Vinyl Flooring (LVP/LVT). The following floor construction is recommended for compliance with the product material warranty.

On new wood frame builds, the preferred floor construction is a 3/4" flooring grade plywood over a joist spacing, with either solid sawn lumber or I-Joists, of 16" on center (oc). This provides the most stable surface for LVP/LVT to be applied over.

On new builds and renovation flooring projects where OSB is in place, or will be the product used as a subfloor replacement, we recommend the following construction:

- 16" oc joist spacing: A 1/2" OSB subfloor is sufficient
- Up to 19.2" oc joist spacing: Use a 23/32" OSB
- Up to 24" oc joist spacing: Use a 7/8" OSB
- Up to 32" oc joist spacing: Use a 1 1/8" OSB

LVP/LVT, because of its supple nature will conform with the subfloor and should be the flooring surface used over framed subfloors with larger joist spacing. Our 5.0mm, 4.5mm products are designed to be laid over electric and hydronic (water) radiant floor heating. For electric installations, be sure to encapsulate the wire under a self-leveling concrete base to a thickness as stipulated by the manufacturer's instruction. Either heating system must be turned OFF at least 2 hours prior to the installation of flooring and the environment must be at room temperature. Following the installation of flooring, leave the heating system off for a further 2 hours and be sure to operate at a temperature as stipulated by the manufacturer's instruction.



CONCRETE SUBFLOORS

1. Concrete subfloors must be dry, smooth, and free from dust, solvent, paint, wax, grease, oil, asphalt sealing compounds and other extraneous materials. The surface must be hard and dense, and free from powder of flaking.
2. New concrete slabs must be thoroughly dry and completely cured (at least six weeks). Curing agents, surface hardeners and other additives may cause adhesive bonding failure. These should be removed by sanding or grinding.
3. All concrete slabs must be checked for moisture before installing the material. Anhydrous Calcium Chloride tests conducted according to ASTM F 1869 and/or In Situ Relative humidity tests as conducted according to ASTM F 2170 are the most commonly accepted test procedures.
4. Holes, grooves, expansion joints and other depressions must be filled with Uzin Utz patching and leveling compound and troweled smooth and feathered even with the surrounding surface.
5. Concrete floors with a radiant heating system are satisfactory, provided the temperature of the concrete floor does not exceed 85°F at any point. Before installing the flooring, the heating system should be turned on to eliminate residual moisture.

Treco will not assume responsibility for floor covering failure due to hydrostatic pressure or moisture vapor emission. The final responsibility for determining if the concrete is dry enough for installation of the flooring lies with the floor covering installer.



EXISTING RESILIENT FLOOR COVERINGS

In the rare cases where removal of the existing resilient floor covering is not an option, the existing flooring must be covered with an Uzin embossing leveler or other appropriate porous underlayment.

WARNING: Installing over existing resilient flooring is risky and the floor is more likely to have indentation issues. The responsibility lies with the installer, to ensure the following:

- Installation must be on grade or suspended only, not below grade.
- Is not textured or embossed that it would telegraph through the new installation. Use embossing leveler to ensure this.
- Only a single layer of flooring, i.e. the existing LVT must be glued to the subfloor, not another flooring product.
- The existing LVT must be fully and firmly bonded on the existing subfloor.
- Waxes, polishes, and other finishes must be entirely removed.
- Indentations or damaged areas must be replaced or repaired.
- Do not sand, dry scrape, bead blast or mechanically pulverize existing resilient flooring, backing or lining felt. These products may contain asbestos fibers that are not readily identifiable. Using the above non-recommended procedures on asbestos-containing material can create asbestos dust. The inhalation of asbestos dust may cause serious bodily harm.
- Ceramic tile should be made smooth by applying a cementitious overlay such as Uzin patching or leveling compound. When the removal of the existing resilient floor covering is not an option, the existing flooring must be covered with an Uzin embossing leveler or equivalent.



INSTALLATION OPTIONS

A. TILE LAYOUT

The room must be accurately measured to square off the area and to determine the center point of the area. The work area should be divided into quadrants designated by striking chalk lines. It is critical that the intersection of the chalk lines be square at 90°.

All border tiles should be of nearly equal dimensions and at least one-half of a tile wide. Careful and precise measurements must be taken during tile layout.

Adjust this established line to accommodate a balanced layout and then transpose this line to a comfortable width away from the starting wall (approximately 2' to 3' wide). Apply the adhesive in this area and begin installing the tiles. Lay all tiles in the same direction, all directional arrows pointing in the same direction.

B. PLANK LAYOUT

It is also important to balance the layout of the plank format. Proper planning and layout will prevent narrow plank widths at wall junctures. Determine layout to prevent having less than 1/2 plank width or very short length pieces. As with all plank products, lay the long dimension of the plank parallel to the long dimension of the work area. Accurately measure

the room to determine the center line, adjust this established line to accommodate a balanced layout and then transpose this line to a comfortable width away from the starting wall (approximately 2' to 3' wide). Apply the adhesive in this area and begin installing planks. The end joints of the planks should be offset or "staggered" no less than 1/3 the length of the planks. Repeat this method throughout the installation.

Perimeter Adhesive – 5.0mm, 4.5mm Specifications Only

Use either Uzin pressure-sensitive adhesive or Titebond 341 to secure the outer perimeter planks or tiles of your room into position. Your inner planks or tiles will not require the use of adhesive when fitted tightly together and will remain in place. The perimeter adhesive will only need to be laid to a depth of just 6" to 9" from the sides of the room. Remember, no expansion gaps required.

Note: On occasion and for peace of mind for some consumers, you may decide to periodically lay a few strips of adhesive or tape within the inner floor areas. Think of it as if you were locking pieces of a jigsaw into a more permanent, fixed position. This concept is optional.



INSTALLATION OPTIONS

C. FULL-SPREAD ADHESIVE – ALL SPECIFICATIONS

This is recommended for commercial installations but optional within residential installations. Use either Uzin KE 2000 pressure-sensitive adhesive or Titebond 341 for the benefit of:

1. Repositioning or replacing single planks or tiles that are accidentally damaged at a future date. Each plank or tile can be individually lifted without affecting the positioning of surrounding planks and tiles.
2. Lifting the planks or tiles which may have been affected by flooding or general water damage. These can be dried and re-used once the sub floor area affected by water is moisture free.

The full- spread pressure sensitive and permanent adhesive installation method are recommended for utility/laundry rooms, washrooms/restrooms, bathrooms, or general high-traffic commercial applications.

D. ADHESIVE APPLICATION

Using recommended notch trowel, follow ALL adhesive application on adhesive pails

E. COMPLETING THE JOB

Drying time is approximately 4 hours and will vary due to installation site temperature, humidity and air flow. Installation over areas of incomplete drying can result in job failure over non-porous surfaces. After installation is complete, roll and cross roll with a 100lb sectional roller. Use hand roller in areas which cannot be reached with large roller. Check 1-2 hours after installing LVT and roll again if necessary.

Cover all exposed edges. Use wood molding or vinyl cove base along all walls, cabinet toe kicks, etc. Use transition strips in doorways or where new flooring joins another floor covering. Caulk along tubs, toilet bowls, etc.

Do not wash the floor for 48 hours after installation.

After 48 hours, damp mop to remove residual surface dirt. Follow appropriate maintenance schedule for Haven LVT.



INSTALLATION OPTIONS

- a. Furniture should be moved onto the newly installed floor using an appliance hand truck over hardboard runways.
- b. Do not place heavy items on the newly installed floor covering for at least 24 hours after completion of the installation. Heavy furniture should be equipped with suitable non-staining, wide-bearing casters.
- c. Floor covering subjected to excessive heat and light exposure is subject to thermal degradation. Use appropriate precautions to minimize potential change on the floor covering.
- d. Oil or petroleum-based products can result in surface staining. Do not track asphalt driveway sealer or automobile oil drips onto the LVT.
- e. Use non-staining walk off mats. Rubber can discolor LVT flooring.

20 YEAR
LIMITED

Commercial
Warranty

LIMITED
LIFETIME

Residential
Warranty

For full warranty information, visit

TIMELESSWOODFLOORS.CA


TIMELESS
LEGACY FLOORS

Learn more at Timelesswoodfloors.ca